

Popup General Instructions

Updated 10/11



*Quality You Can Trust...From
North America's Largest Roofing Manufacturer!™*

Presto Pop-Up Frames

1. Lay pop-up frame on ground (fig. A-1) and pull straight up to expand (fig. A-2).
2. Interlock steel hooks to hold frames securely in place (fig. B).
3. Attach graphic to velcro perimeter (fig. C).
5. (Optional) Attach end panel bracket to frame using flat-head screw (fig. D).
6. (Optional) Wrap graphic around end panel (fig. E).
7. (Replacement) Unscrew, remove nut and X Bracket leaving the screw intact, replace the X Bracket and re-tighten nut(Fig F).

Applicable Products:

PFK-13	PFK-33	PFK-33C
PFK-22	PFK-43	PFK-43C
PFK-23	PFK-44	
PFK-32	PFK-53	

