

Perimeter Half Sheet Table

Building Width	Building Height	Number of EverGuard TPO 60" Half Sheets	Number of EverGuard PVC 36" Half Sheets
<200'	0-34'	1	2
	35-100'	2	3
	>100'	Formula: Install half sheets throughout the perimeter and corner region. The width of this region is defined as the least of the following two measurements: 0.1 x building width or 0.4 x building height Note: the minimum width is 4'	
≥200	any height		

NOTE: FM attachment requires the Formula calculation.