

EverGuard® EPDM Fully Adhered System Application Instructions

Information Sheet

Updated: 8/02



*Quality You Can Trust Since 1886...
From North America's Largest Roofing Manufacturer™*

EVERGUARD® EPDM FULLY ADHERED SYSTEM APPLICATION INSTRUCTIONS TABLE OF CONTENTS

2.01.1	GENERAL.....	2
2.02.1	CONTRACTOR SUBMITTALS.....	2
2.03.1	JOB SITE CONSIDERATIONS (CAUTIONS AND WARNINGS).....	2
2.04.1	ROOF SUBSTRATE PREPARATION:.....	3
2.05.1	WOOD NAILER LOCATION AND INSTALLATION.....	4
2.06.1	INSULATION INSTALLATION.....	4
2.07.1	MEMBRANE INSTALLATION.....	5
2.08.1	MEMBRANE SEAMING.....	6
2.09.1	ADDITIONAL MEMBRANE SECUREMENT AND BASE TIE-IN FLASHING.....	7
2.10.1	FLASHING INSTALLATION AND SEAMING USING EVERGUARD EPDM SPLICE ADHESIVE.....	8
2.11.1	SEAM EDGE TREATMENT.....	9
2.12.1	FLASHING - PENETRATIONS.....	9
2.13.1	FLASHING - WALLS, PARAPETS, MECHANICAL EQUIPMENT CURBS, SKYLIGHTS, ETC.....	11
2.14.1	FLASHING - GRAVEL STOPS OR ROOF EDGE METALS.....	11
2.15.1	MEMBRANE REPAIR.....	12
2.16.1	TEMPORARY CLOSURE.....	13
2.17.1	TOPCOAT® COATING.....	13
2.18.1	ROOF WALKWAYS.....	13
2.19.1	SHEET METAL WORK.....	14

IMPORTANT: ALWAYS REVIEW SAFETY INFORMATION ON LABEL AND MSD SHEETS

APPLICATION INSTRUCTIONS FOR EVERGUARD® EPDM FULLY ADHERED ROOFING SYSTEMS

2.01.1 GENERAL

This section of the EverGuard EPDM Application and Specifications Manual contains instructions in the installation of EverGuard EPDM Fully Adhered Systems. Reference to the Design Section, Technical Information Sheets (T.I.S.), and other sections of EverGuard EPDM's Application and Specifications Manual is necessary to assure that the finished roof system is installed in compliance with EverGuard EPDM requirements.

2.02.1 CONTRACTOR SUBMITTALS

A. Submit Pre-Installation Form (PIF):

Submit a completed Pre-Installation Form (PIF) to EverGuard EPDM Services a minimum of 14 days prior to project start-up.

NOTE: IF A PROPOSED APPLICATION FALLS OUTSIDE OF THIS SPECIFICATION, CONTACT EVERGUARD CONTRACTOR SERVICES FOR ADDITIONAL INFORMATION.

B. Submit Pull-out Tests Results (When Required):

1. When pull-out tests are required, submit a complete listing of the pull-out values to EverGuard Contractor Services for review.
2. Submit a roof drawing showing the locations where the pull-out tests were performed.

C. Submit Notice of Acceptance (NOA):

Submit the Notice of Acceptance (NOA) and Roof Drawing within 30 days of completion of the project. All pertinent information, such as penetrations, dimensions, building height and edge conditions, must be included. An inspection will be scheduled (if a system guarantee is requested). An EverGuard Inspector will perform the inspection to determine compliance with EverGuard EPDM specifications and details.

Items found that are not in conformance with EverGuard EPDM specifications will be documented by the EverGuard Inspector and must be corrected by the Applicator prior to issuance of the requested guarantee.

D. Submit Completed Inspection Results Form (IRF):

Upon completion of any necessary repair(s), sign and submit the completed Inspection Results Form (IRF) form to EverGuard Contractor Services within 60 days of inspection.

2.03.1 JOB SITE CONSIDERATIONS (CAUTION AND WARNINGS)

- A. All adhesives, sealants and cleaning materials are **FLAMMABLE**. Keep them away from ALL ignition sources (i.e., flames, fire, sparks, etc.). Do not smoke while using these materials.
- B. Consult container labels, Material Safety Data Sheets and Technical Information Sheets for specific safety instructions for all products used on the project.
- C. Be careful when installing fasteners to avoid possible conduits and other piping in and under the deck.
- D. Fumes from adhesive solvents may be drawn into the building during installation through rooftop intakes. Refer to EverGuard EPDM Technical Information Sheet "Recommended Guidelines for Application of Roofing Materials to an Occupied Building" for guidelines.
- E. Store EverGuard EPDM membrane in the original undisturbed plastic wrap in a manner to protect it from becoming damaged.
- F. Do not use oil-base or bituminous-base roof cement with EverGuard EPDM membranes.
- G. Store insulation properly and protected from ignition sources, moisture and damage.

- H. When the outside temperature is below 40 °F (4.4 °C), certain combinations of temperature and humidity may cause condensation on the surface of solvent-based adhesives and primers. If condensation occurs, discontinue the application. When the ambient air conditions no longer cause condensation on adhesive surfaces, re-apply additional adhesive or primer and proceed.
1. The consistency of sealants, adhesives and primers will begin to thicken as the temperature drops. To minimize this, the following is recommended:
 - a. Start work with sealants, adhesives and primers that have been stored between 60 °F and 80 °F (15.5 °C and 26.7 °C). Insulated heated boxes may be helpful.
 - b. Complete test areas to determine if conditions will cause problems such as condensation with the application of the material.
 - c. Stop the operation or change to another warm container when material becomes too thick to properly apply.
 2. Never use heat guns or open flames to dry adhesives and primers.
 3. No-fold or single fold panels are easier to apply in cold weather and are recommended. If using Water-Based Bonding Adhesive, temperatures must be at least 40 °F (4.4 °C) and rising for the material to apply and perform as designed. Expect longer drying times at lower temperatures and higher humidity.

2.04.1 ROOF SUBSTRATE PREPARATION

A. Correct Substrate Defects:

1. Defects that need to be corrected before work can commence should be brought to the attention of the General Contractor or Owner in writing and addressed.
2. For re-roofing applications, remove existing roof system components as specified by the project designer. If components are discovered during installation that could be detrimental to the performance of the new roof system, they should be brought to the attention of the project designer for corrective action.
3. Good roofing practice requires a complete tear-off to the structural deck if soundness and integrity of the existing roof system cannot be verified. Recovering an existing roof system is an alternative to removing existing roof components. However, non-destructive testing in conjunction with core cuts must be completed to determine the condition of the existing roof system and decking.
4. The building owner or project designer is responsible for assuring that all wet insulation and wet substrate materials are removed in a re-roofing application. The best diagnostic technique to locate wet areas is taking and evaluating a series of roof cuts. There are three other techniques that are currently available to make this determination by indirect means. These are: nuclear moisture detection, infrared thermography and electric capacitance. These techniques provide measurement of factors that can be associated with the presence of moisture, which can then be correlated to the roofing cuts to verify the results of the non-destructive testing.

B. Remove Moisture:

Ponded water, snow, frost and/or ice, present in more than trace amounts, must be removed from the work surface(s) prior to installing the EverGuard® EPDM Fully Adhered System.

C. Prepare Surface:

Acceptable substrates to which the EverGuard EPDM Fully Adhered System will be installed must be properly prepared prior to membrane installation. The surface must be relatively even, clean, dry, smooth, free of sharp edges, fins, loose or foreign materials, oil, grease and other materials that may damage the membrane. Rough surfaces that could cause damage to the membrane must be overlaid with insulation.

D. Fill Voids:

All surface voids in the immediate substrate greater than 1/4" (6.35 mm) wide must be filled with insulation.

E. Install Vapor Retarder (When Specified):

Install a vapor retarder as specified by the project designer. Refer to the System Design Guide of this manual for additional information.

2.05.1 WOOD NAILER LOCATION AND INSTALLATION

Wood nailers must be installed as specified by the project designer or as noted in EverGuard® EPDM Details and the System Design Guide. Install wood nailers as follows:

A. Position Wood Nailer:

Total wood nailer height must match the total thickness of insulation being used and should be installed with a 1/8" (3.2 mm) gap between each length and each change of direction.

B. Secure Wood Nailer:

Wood nailers must be firmly fastened to the deck or building. Mechanically fasten wood nailers to resist a force of 200 lbf (890 N) in any direction. Refer to attachment requirements as specified by the project designer.

C. Taper Wood Nailer:

The wood nailer must be tapered (if applicable) so that it will always be flush at the point of contact with the insulation (refer to EverGuard EPDM Details).

D. Chemical Treatment of Wood Nailer:

Chemical treatment for fire resistance or other purposes (other than pressure treating for rot resistance, i.e. "Wolmanized" or "Osiose K-33") may affect the performance of the EverGuard EPDM membrane and accessories. Submit MSDS sheets for any chemically treated lumber that comes in contact with the EverGuard EPDM Membrane, with active ingredients listed, to EverGuard Contractor Services for acceptance regarding compatibility.

E. Installation of Wood Nailers by Others:

Make these specifications and details available when nailers are to be installed by others. Work that compromises the integrity of the system may jeopardize the guarantee for the entire project.

2.06.1 INSULATION INSTALLATION

A. Install Insulation:

Install only as much insulation as can be covered with roofing membrane and completed before the end of the day's work or before the onset of inclement weather.

B. Fit Insulation:

Neatly fit insulation to all penetrations, projections, and nailers. Insulation should be loosely fitted, with gaps greater than 1/4" (6.3 mm) filled with acceptable insulation. Under no circumstances should the membrane be left unsupported over a space greater than 1/4" (6.3 mm). Tapered insulation with acceptable facers for bonding must be installed around roof drains so as to provide proper slope for drainage as shown in EverGuard EPDM Details.

C. Attach Insulation:

Insulation must be attached using EverGuard Insulation Plates and Fasteners.

1. Fastening pattern will vary depending on code compliance.
2. When installing a multi-layer insulation assembly, the fastening pattern is determined by the type and thickness of the top layer of insulation.

NOTE: 15-YEAR RECOVERS AND 20-YEAR GUARANTEES REQUIRE THE USE OF EVERGUARD HEAVY DUTY (EVERGUARD HD) FASTENERS FOR INSULATION ATTACHMENT. IF THE DECK IS STRUCTURAL CONCRETE, EVERGUARD HD FASTENERS OR CONCRETE DRIVES MUST BE USED.

3. As an option and depending on the deck type, insulation may be attached using ASTM D 312 Type III or Type IV asphalt or an EverGuard®-accepted insulation adhesive. Specific information may be found in the System Design Guide of this Manual.
- D. Stagger Insulation Joints:**
When installing multiple layers of insulation, it is good roofing practice to stagger all joints between layers but staggering is not required for the issuance of a GAFMC guarantee.

2.07.1 MEMBRANE INSTALLATION

- A. Place Membrane and Allow to Relax:**
Place membrane panel, without stretching, over the acceptable substrate and allow to relax for a minimum of 30 minutes before splicing or attaching. During cold weather application, it is recommended that the smallest panels be used to minimize folds. (Larger panels have factory folds which may take longer to relax during cold weather.) The EverGuard EPDM Fully Adhered System must be installed so that the seams shed the flow of water.
- B. Fold the Membrane Back:**
After making sure the sheet is placed in its final position allowing for the minimum lap width per EverGuard EPDM specifications, fold it back evenly onto itself without wrinkles to expose the underside mating surface of the sheet.
- C. Remove Dusting Agent and Dirt:**
Sweep the mating surfaces with a stiff broom to remove any dusting agent or dirt that may have accumulated.
- D. Apply the Bonding Adhesive:**
Apply bonding adhesive with either a 9" (228 mm) wide solvent-resistant paint roller or a commercial-grade adhesive sprayer. Adhesive must be applied in a relatively uniform thickness to both surfaces at approximately the same time. If adhesive is spray-applied, it must be back-rolled with a paint roller to assure proper contact and coverage. Refer to EverGuard EPDM Technical Information Sheets and container labels for specific application requirements and coverage rates.
- E. Stop Bonding Adhesive Short of Seam Area:**
Be careful not to apply bonding adhesive over an area that is to be later spliced to another sheet or flashing. All bonding adhesive must be completely removed from the seam area.
- F. Test Bonding Adhesive for Readiness (Touch-Push Test):**
Allow the bonding adhesive to flash off. Touch the adhesive surface in the thickest area with a clean, dry finger to be certain that the adhesive does not stick or string. As you are touching the adhesive, push forward on the adhesive at an angle to assure that the adhesive is ready throughout its thickness. If either motion exposes wet or stringy adhesive when the finger is lifted, the adhesive is not ready for mating. Flash-off time will vary depending on ambient conditions.
- G. Bond the Membrane to the Substrate:**
Starting at the fold, roll the previously coated portion of the membrane into the coated substrate slowly and evenly to minimize wrinkles.
- H. Broom the Membrane:**
To assure proper contact, compress the bonded half of the membrane to the substrate with a stiff push broom.
- I. Repeat Procedure to Complete the Membrane Installation:**
Fold the un-adhered half of the membrane back onto itself, and repeat the procedure.

2.08.1 MEMBRANE SEAMING

A. Position and Fold Back the Lap Edge

Position the membrane at the seam area by overlapping membrane 4" (102 mm) for 3" (76 mm) EverGuard® EPDM Seam Tape and 8" (203 mm) for 7" (178 mm) EverGuard EPDM Seam Tape. Once the membrane is in place, mark the bottom membrane 1/2" (12.7 mm) to 3/4" (19 mm) from the edge of the top membrane every 4' (1.2 m) to 6' (1.8 m) using the marking crayon provided with the EverGuard EPDM Seam Tape. Tack the membrane back with EverGuard EPDM Primer as necessary to hold back the membrane at the splicing area.

20-YEAR SYSTEM REQUIREMENTS:

**7" (178 mm) EVERGUARD EPDM SEAM TAPE
OR
3" (76 mm) EVERGUARD EPDM SEAM TAPE WITH THE
APPLICATION OF EVERGUARD EPDM FLASHING TAPE
OVER THE ENTIRE SEAM LENGTH.**

REFER TO 20-YEAR EVERGUARD DETAILS FOR SPECIFIC REQUIREMENTS.

B. Apply EverGuard EPDM Primer to Seam Area:

Remove excess amounts of dusting agent on the membrane and at factory splices using a stiff push broom. Stir EverGuard EPDM Primer thoroughly before and during use. Dip the EverGuard EPDM Scrub Pad or Stand-Up Tool into the bucket of EverGuard EPDM Primer, keeping the pad flat. Apply the EverGuard EPDM Primer using long back and forth type strokes with pressure along the length of the splicing area until surfaces become a dark gray in color. Apply EverGuard EPDM Primer to both surfaces at the same time. Change the scrub pad every 200 feet (61 m) of seam or when the pad will no longer hold the proper amount of EverGuard EPDM Primer. Additional scrubbing is required at all factory seams and at areas that may have become contaminated or have excess amounts of dusting agent.

C. Apply the EverGuard EPDM Seam Tape:

After allowing the EverGuard EPDM Primer to dry properly using the Touch-Push Test, apply the EverGuard EPDM Seam Tape to the bottom membrane, aligning the edge of the release paper with the markings. Immediately roll the seam tape with a 3" to 4" (76 mm to 102 mm) wide silicone hand roller, a short nap 3" (76 mm) paint roller, or a clean EverGuard EPDM Scrub pad or EverGuard EPDM Scrub Stand Up Tool pad and handle.

D. Check the Seam Tape Alignment:

When the EverGuard EPDM Seam Tape has been installed for the entire seam length, position the top membrane to rest on top of the tape's release paper backing. Trim the top panel as necessary to assure that 1/8" to 1/2" (3.1mm to 12.7mm) of the EverGuard EPDM Seam Tape will be exposed on the finished seam.

E. Remove Release Paper Backing:

To remove the paper backing from the tape, roll back the EPDM membrane and peel the release paper backing off the EverGuard EPDM Seam Tape by pulling against the weight of the bottom panel at approximately a 45° angle to the tape and parallel with the roof surface. Allow the top membrane to fall freely onto the exposed EverGuard EPDM Seam Tape. Broom the entire length of the seam at a 45° angle as the release paper is being removed.

F. Roll the Seam:

Roll the seam using a 1-1/2" to 2" (38 mm - 51 mm) wide silicone hand roller, first across the seam and then along the entire length of the seam.

G. Special Considerations (End Laps, "T" Joints, etc.):

1. **End Laps:** When the seam is greater in length than the tape, the adjoining EverGuard EPDM Seam Tape must be overlapped a minimum of 1" (25.4 mm).
2. **Trim EverGuard EPDM Seam Tape at "T" Joints:**
Trim EverGuard EPDM Seam Tape so that the edge of EverGuard EPDM Seam Tape and the edge of the membrane are flush beneath the "T" joint area.

3. **“T” Joints:**
Apply a section of EverGuard® EPDM Flashing Tape or EverGuard EPDM Joint Cover over the T” joint area.
4. **Using EverGuard EPDM Seam Tape with Cured EPDM as Flashing:**
If cured EPDM is used as flashing, apply an 8" (203 mm) long section of EverGuard EPDM Flashing Tape or an EverGuard EPDM Joint Cover over the intersection of the flashing and field seams.

2.09.1 ADDITIONAL MEMBRANE SECUREMENT and BASE TIE-IN FLASHING

Provide Membrane Securement

Secure the membrane (base tie-in) at all locations where the membrane goes through an angle change greater than 2" (25.4 mm) in 12" (305 mm) (i.e., roof edges, curbs, interior walls, etc.).

OPTION 1: EverGuard EPDM Reinforced Tape Strip (RTS)

Attach the RTS to the penetration, parapet wall or deck using EverGuard 2" (51 mm) Seam Plates or EverGuard EPDM Batten Bars fastened a maximum of 12" (305 mm) o.c. Roll the membrane into place and then fold back, exposing the underside of the membrane and the RTS. When using batten bars, apply EverGuard EPDM All Purpose Sealant over each fastener head, assuring that the fastener head is completely covered.

Apply EverGuard EPDM Primer to the membrane where it will mate with the EverGuard EPDM Seam Tape and allow to dry. Apply EverGuard EPDM Bonding Adhesive to the back half of the RTS, to the membrane that is to be bonded to the penetration or wall and to the penetration or wall itself.

After the surfaces have dried properly as determined by using the Touch-Push Test, remove the release paper from the EverGuard EPDM Reinforced Tape Strip and roll the membrane into place, assuring a tight fit into the transition between the horizontal and vertical surfaces. Continue to roll the membrane up the wall and broom in place with a stiff push broom. Roll the membrane over the EverGuard EPDM Seam Tape with a 1-1/2" to 2" (38 mm x 51 mm) wide silicone roller across the tape and then along its length.

Complete vertical laps seams as described in the lap splice section of this specification. Install an EverGuard EPDM Joint Cover over any vertical lap splices that go through an angle change (refer to EverGuard EPDM Details).

NOTE: EVERGUARD EPDM REINFORCED TAPE STRIP IS REQUIRED FOR 20-YEAR GUARANTEED SYSTEMS.

OPTION 2: EverGuard EPDM Batten Bar

Install the EverGuard EPDM Membrane per EverGuard EPDM Details and attach to the vertical substrate using EverGuard EPDM Batten Bars at a maximum of 12" (305 mm) o.c. (Polymer Battens may only be used over wood or metal substrates). Apply EverGuard EPDM All Purpose Sealant over each fastener head, assuring that the fastener head is completely covered.

Cut a piece of flashing from EverGuard EPDM Membrane or EverGuard EPDM Flashing Tape large enough to completely cover the substrate of the wall or curb and extend onto the roof membrane a minimum of 3" (76 mm) [Note: must be 7" (178 mm) for 20-year guaranteed systems]. Complete the splice between flashing and the main roof membrane using EverGuard EPDM Seam Tape before adhering flashing to the vertical surface. Provide lap seams in accordance with EverGuard EPDM Details.

Apply bonding adhesive at about the same time to both the flashing and the surface to which it is being bonded so as to allow approximately the same flash-off time. Apply bonding adhesive evenly to avoid globs.

After the bonding adhesive has dried properly as determined by the Touch-Push Test, roll the flashing into the adhesive evenly and carefully so as to minimize wrinkles. Broom the flashing to the substrate with a stiff push broom to assure proper contact.

2.10.1 FLASHING INSTALLATION AND SEAMING USING EVERGUARD EPDM SPLICE ADHESIVE

When Option #2 above is used, seams are typically completed using EverGuard EPDM Seam Tape. Where splice adhesive is allowed by EverGuard EPDM Details, use the following procedure for completing the flashing:

- A. Attach membrane at the curb in accordance with EverGuard EPDM Details.
- B. Cut a section of membrane equal in length to the perimeter of the curb plus 3" (76 mm) (example: A 4'x 4' (1.2 m x 1.2 m) curb would require a 16'-3" (4.98 m) length of membrane). Note: The additional 3" (76 mm) of material is not required if the flashing is butted at the final corner in lieu of a 3" (76 mm) lap seam.
- C. Cut the width of the membrane equal to the height of the curb plus a base lap of 3" (76 mm) and 2" (51 mm) to go over the top of the curb.
- D. Place the membrane on a flat surface in close proximity to the curb.
- E. Clean the flashing and roof membrane area to be seamed using EverGuard EPDM Scrub Pad or Stand-Up Tool with EverGuard EPDM Primer to remove all dusting agent, dirt, and other contaminants that will affect the finished seam and allow to dry. Additional cleaning may be required to assure that the membrane is completely cleaned. Additional cleaning at factory seams is required to remove accumulations of dusting agent. EverGuard EPDM Scrub pads must be discarded every 200 lineal feet or when they become dirty and replaced with clean ones to assure proper cleaning. Proper cleaning has been achieved when the membrane surface is dark gray in color and no streaking is evident. EverGuard EPDM Uncured Flashing does not require cleaning unless it has been contaminated.

DO NOT USE CIRCULAR MOTIONS APPLYING SPLICE ADHESIVE. DO NOT USE PAINT ROLLERS, SPRAY EQUIPMENT OR MECHANICAL EQUIPMENT FOR THE APPLICATION OF SPLICE ADHESIVE. DO NOT USE LONG HANDLES ON SPLICE ADHESIVE BRUSHES TO APPLY SPLICE ADHESIVE.

- F. Apply EverGuard® EPDM Bonding Adhesive to the curb and to the flashing membrane. Do not apply bonding adhesive to the area of the flashing that has been cleaned in Step #E. While the bonding adhesive is drying, apply EverGuard EPDM Splice Adhesive to the flashing membrane and roof membrane. Thoroughly stir EverGuard EPDM Splice Adhesive before and during use. Apply the Splice Adhesive using a EverGuard EPDM Splice Adhesive Brush or a 3" to 4" (76 mm to 101 mm) wide 1/2" (12.7 mm) thick, solvent-resistant paint brush in a smooth, even coat with long brush strokes, such that brush marks bleed out, yielding a smooth, glossy adhesive surface. Apply Splice Adhesive to both mating surfaces at about the same time.
- G. Test the bonding adhesive and splice adhesive for readiness by using the Touch-Push Test. Touch the adhesive surface in the thickest area with a clean dry finger to be certain that the adhesive does not stick or string. As you are touching the adhesive, push forward on the adhesive at an angle to assure that the adhesive is ready throughout its thickness. If either motion exposes wet or stringy adhesive when the finger is lifted, the adhesive is not ready for mating. Flash-off time will vary depending on ambient conditions.

- H. After the bonding and splice adhesives have dried properly, mate the flashing to the curb (use 2-3 people depending on the size of the curb involved). This is accomplished by folding the splice area back on itself, picking up the flashing, and wrapping the entire curb leaving the seam area folded upwards. The flashing membrane is now bonded to the curb only.
- I. To complete the splice between the flashing and roof membrane, cut the flashing membrane down to each corner of the curb. Work the flashing membrane into the angle change as tightly as possible, then allow the remainder of the flashing membrane to fall into place.
- J. Roll the splice with a 1-1/2" (38 mm) silicone coated steel roller in both directions along the splice edge. Broom the membrane over the curb to assure proper mating of the bonding adhesive.
- K. Apply 9" (228 mm) EverGuard EPDM Corner Flashing or 9" (228 mm) EverGuard EPDM Flashing Tape at all corners per EverGuard EPDM current requirements, including Seam Edge Treatment.
- L. Wait at least 4 hours after the completion of a seam to apply Seam Edge Treatment (Splice Adhesive and Lap Sealant) unless weather is threatening. If weather is threatening, Seam Edge Treatment must be applied before leaving the project. When weather is not threatening, Seam Edge Treatment must be applied no later than the end of the next day following completion of the seam.

20-YEAR SYSTEM REQUIREMENTS:

**7" (178 mm) EVERGUARD EPDM SEAM TAPE
OR
3" (76 mm) EVERGUARD EPDM SEAM TAPE WITH THE APPLICATION OF
EVERGUARD EPDM FLASHING TAPE OVER THE ENTIRE SEAM LENGTH.**

REFER TO 20-YEAR EVERGUARD EPDM DETAILS FOR SPECIFIC REQUIREMENTS.

**2.11.1 SEAM EDGE TREATMENT
(REQUIRED WHEN USING SPLICE ADHESIVE AS SHOWN ON EVERGUARD EPDM DETAILS AND
AT CUT EDGES OF EVERGUARD EPDM .060 REINFORCED MEMBRANE)**

- 1. **Apply Splice Adhesive to Seam Edge:**
Using a Splice Adhesive brush, apply EverGuard EPDM Splice Adhesive a minimum of 1" (25.4 mm) on either side of the seam edge. Allow the Splice Adhesive to dry. If the seam edge has become contaminated, it will be necessary to clean the edge with EverGuard EPDM Primer prior to applying the adhesive
- 2. **Apply the Lap Sealant to Seam Edge:**
Apply a continuous bead of Lap Sealant, approximately 3/8" x 1/4" (9.5 mm x 6.35 mm) 20-22 lineal feet (6 m - 6.7 m) per 10 oz. (295 cc) tube centered over the seam edge using a standard caulking nozzle. Using the Lap Sealant tool, feather the Lap Sealant immediately, taking care to leave a mound of sealant directly over the seam edge (refer to Lap Splice Details). Alternatively, Lap Sealant may be applied using the plastic nozzle applicator, assuring the applicator is centered at the seam edge.

2.12.1 FLASHING - PENETRATIONS

- A. **General:**
 - 1. Remove all loose existing flashing (i.e. metal, bituminous materials, mastic, etc.).
 - 2. Flash all penetrations passing through the membrane.
 - 3. The flashing seal must be made directly to the penetration.

B. Pipes, Round Supports, Structural Steel Tubing, etc.:

1. Flash penetrations with EverGuard® EPDM Universal Pipe Boots wherever possible. Do not cut or patch EverGuard EPDM Universal Pipe Boots to assist in their installation, except when cutting for initial collar size.
2. Flash penetrations using EverGuard EPDM Uncured Flashing when the use of EverGuard EPDM Universal Pipe Boots is not possible.
3. Refer to EverGuard EPDM Technical Information Sheet for minimum and maximum pipe diameters that can be successfully flashed with EverGuard EPDM Universal Pipe Boots.
4. Structural Steel Tubing: Use a field-fabricated pipe flashing detail when the corner radius is greater than 1/4" (6.35 mm) and the longest side of the tube does not exceed 12" (305 mm). When the tube exceeds 12" (305 mm), use a standard curb detail, including base tie-in and suitable termination.

C. Roof Drains:

These specifications apply for installation of cast iron drains only. For all other drain types, contact EverGuard Contractor Services.

1. Remove existing clamping ring. Remove any broken clamping hardware and replace.
2. Remove all existing flashing (including lead flashing), roofing materials and cement from the existing drain in preparation for membrane and Water Block Seal.
3. Provide a clean even finish on the mating surfaces between the clamping ring and the drain bowl.
4. Install tapered insulation with suitable bonding surfaces around the drain to provide a smooth transition from the roof surface to the drain. Slope into drain cannot be greater than 2" in 12" (25.4 mm in 305 mm).
5. Position the membrane and cut a hole for the roof drain allowing a 1/2" (12.7 mm) to 3/4" (19.1 mm) of membrane inside the clamping ring.
6. Make round holes in the membrane to align with clamping bolts (a paper punch may be used). Do not cut the membrane back to the bolt holes.
7. Install EverGuard Water Block on the clamping ring seat flange below the membrane. Use a minimum of one half of a 10 oz. (295 cc) tube for a 10" (254 mm) drain.
8. Install the roof drain clamping ring and all clamping bolts. Tighten the clamping bolts to achieve constant compression

D. Pipe Clusters and Unusual Shaped Penetrations:

1. Fabricate penetration pockets to allow a minimum clearance of 1" (25.4 mm) between the penetration(s) and all sides.
2. Secure penetration pockets and flash per EverGuard EPDM Details.
3. Fill penetration pockets with EverGuard EPDM Pourable Sealer and mound to shed water. Pourable Sealer must be a minimum of 2" (51 mm) deep and 1" (25.4 mm) thick around the penetrations.

E. Hot Pipes:

Protect the EverGuard EPDM components from direct contact with steam or heat sources when the in-service temperature is in excess of 140 °F (60 °C). In all such cases flash to an intermediate "cool" sleeve.

F. Flexible Penetrations

Provide a weathertight gooseneck set in Water Block and secured to the deck.

Flash in accordance with EverGuard® EPDM Details.

G. Scuppers:

1. Provide and install a new welded watertight sleeve.
2. Set welded watertight scupper in Water Block and secure scupper to the structure.
3. Flash in accordance with EverGuard EPDM Details.

H. Expansion Joints:

Install where specified by the project designer. Install expansion joints in accordance with EverGuard EPDM details.

NOTE: WHEN INSTALLING A SYSTEM FOR A 20-YEAR GUARANTEE, REFER TO THE 20-YEAR SYSTEM DETAILS WHICH ARE PART OF THIS MANUAL.

2.13.1 FLASHING - WALLS, PARAPETS, MECHANICAL EQUIPMENT CURBS, SKYLIGHTS, ETC.

A. General:

Using the largest pieces of EverGuard EPDM Flashing Tape or EverGuard EPDM membrane practical, flash all walls, parapets, curbs, etc., to the height as specified by the project designer.

B. Evaluate Substrate:

See chart in the System Design Guide section of this manual.

C. Install Additional Membrane Securement at Curbs, Penetrations, Walls, etc.:

Refer to Section 2.09.1 of this specification.

D. Provide Termination:

Provide termination directly to the vertical substrate as shown in EverGuard EPDM Details.

E. Provide Intermediate Attachment:

Intermediate attachment of membrane is required at 36" (914 mm) intervals in accordance with EverGuard EPDM Details unless:

1. The wall surface is smooth without noticeable high spots or depressions (i.e., plywood, poured or precast concrete, or hollow core block or masonry walls where joints are flush with masonry surface),

AND

2. The termination is either a Termination Bar or membrane has been installed underneath a coping to the outside edge of the wall.

2.14.1 FLASHING - GRAVEL STOPS or ROOF EDGE METALS

A. Flash Gravel Stops or Roof Edge Metals using EverGuard EPDM Flashing Tape:

1. Clean the Membrane and Metal Edge:

Remove excess amounts of dusting agent by brooming. Apply EverGuard EPDM Primer to the metal edging and membrane as described in EverGuard EPDM Specifications. Allow the

EverGuard EPDM Primer to flash off.

2. Apply EverGuard EPDM Flashing Tape:

Place the roll of EverGuard EPDM Flashing Tape on the roof a few feet ahead of the application starting point, positioned so that it unrolls from the top of the roll (release paper will be on top). Remove approximately 2' to 3' (.6 m to .9 m) of release paper and apply to the metal flange and EverGuard EPDM Membrane. Lap adjacent rolls of EverGuard EPDM Flashing Tape a minimum of 1" (25.4 mm).

3. Roll the EverGuard EPDM Flashing Tape:

With a 1-1/2" to 2" (38 mm to 51 mm) wide silicone hand roller, roll the EverGuard EPDM Flashing Tape to assure proper adhesion. Additional attention must be given to factory seam intersections and to any change in plane.

4. Special Considerations (End Laps, "T" Joints, etc.):

Apply 6" (152.4 mm) length of EverGuard EPDM Flashing Tape, an EverGuard EPDM Joint Cover or 6" x 6" (152.4 mm x 152.4 mm) EverGuard EPDM Uncured Flashing to the inside edge of the EverGuard EPDM Flashing Tape at all overlaps (refer to details).

- b. Apply 6" (152.4 mm) length of EverGuard® EPDM Flashing Tape, an EverGuard EPDM Joint Cover or 6" x 6" (152.4 mm x 152.4 mm) EverGuard EPDM Uncured Flashing at all intersections between the EverGuard EPDM Flashing Tape and field-fabricated seams (Refer to Details).
 - c. If the roof edge includes a gravel stop and sealant is not applied between the laps in the metal edging, an additional piece of EverGuard EPDM Flashing Tape must be applied over the metal lap to the top of the gravel stop, after the initial application of EverGuard EPDM Flashing Tape. Seam Edge Treatment shall be applied at the intersections of the two flashing sections.
- B. Optimal Application:**
- 1. The optimal use of EverGuard EPDM Flashing Tape is where a 3" (76 mm) metal flange is being used. This will provide the minimum 2" (51 mm) seam to the EverGuard EPDM Membrane, with the remaining 3" (76 mm) of the material completely covering the metal flange.
 - 2. If a flange wider than 3" (76 mm) is used, the joints of the sheet metal edge must be flashed using EverGuard EPDM Flashing Tape and EverGuard EPDM Primer. In addition, 3" (76 mm) EverGuard EPDM Seam Tape should be placed in the sheet metal laps to help seal the metal edge.
- C. Special Considerations for Copper Edging:**
- Copper may be weathered or coated with an anti-tarnish lacquer which makes adhesion difficult. Therefore, the copper system must be cleaned to receive the EverGuard EPDM Flashing Tape. GAFMC requires that the copper be scrubbed with acetone or lacquer thinner, using clean cotton cloths. Cleaning before installation of the metal is recommended. However, cleaning can take place after metal is attached if care is taken not to allow the solvents to come into contact with the membrane. After the cleaner dries, apply EverGuard EPDM Primer and EverGuard EPDM Flashing Tape per EverGuard EPDM Specifications.

NOTE: WHEN INSTALLING A SYSTEM FOR A 20-YEAR GUARANTEE, REFER TO THE 20-YEAR SYSTEM DETAILS WHICH ARE PART OF THIS MANUAL.

2.15.1 MEMBRANE REPAIR

- A. Repair Cuts/Punctures in the Membrane or Wrinkles Within 18" (458 mm) of a Seam:**
- 1. A wrinkle running toward a seam or within 18" (458 mm) of a seam must be repaired. The wrinkle must be cut out so that the membrane lays flat and patched with a piece of EPDM membrane having no factory seams that extends a minimum of 3" (76 mm) beyond the boundaries of the cut in all directions. If the wrinkle occurs through EverGuard EPDM Flashing Tape or EverGuard EPDM Uncured Flashing, like material must be used for repair. EverGuard EPDM Flashing Tape or EverGuard EPDM Uncured Flashing may not extend onto the roof surface more than 6" (152 mm). EVERGUARD EPDM FLASHING TAPE OR EVERGUARD EPDM UNCURED FLASHING CANNOT BE USED TO REPAIR CURED MEMBRANE. If repairing of the same wrinkle must continue, then EPDM membrane must be used. Install the EPDM repair membrane first, and round all corners of the repair piece.
 - 2. Repair a cut or puncture in the EPDM membrane with EPDM membrane. The repair must extend a minimum of 3" (76 mm) beyond the boundary of the affected area in all directions. Round all corners of the repair piece (example: a pinhole will require a minimum 6" x 6" (152 mm x 152 mm) EPDM patch).
- B. Clean the Membrane:**
- 1. When repairing membrane which has been in service, it is necessary to remove accumulated dirt. Scrub the membrane with a scrub brush and warm soapy water, rinse with clear water and dry with clean cotton cloths. Clean the area using EverGuard EPDM Scrub pad with EverGuard EPDM Primer. Additional cleaning using EverGuard EPDM Primer is often necessary.

C. Install Repair Material:

Repairs must be made with EverGuard EPDM Splice Adhesive. Refer to the Flashing Seam Details of this manual for application requirements of Splice Adhesive.

WHEN INSTALLING A 20-YEAR REINFORCED SYSTEM AND MEMBRANE REPAIR IS NECESSARY, A SECOND LAYER OF MEMBRANE IS REQUIRED OVER THE INITIAL REPAIR PIECE SPLICED A MINIMUM OF 3" (76 mm) ONTO THE FIELD MEMBRANE USING SPLICE ADHESIVE, FOLLOWED BY THE APPLICATION OF SEAM EDGE TREATMENT.

2.16.1 TEMPORARY CLOSURE (NOT WARRANTED BY EVERGUARD)

Temporary closures to assure that moisture does not damage any completed section of the new roofing system are the responsibility of the applicator. Installation of flashings, terminations and temporary closures must be completed as required to provide a watertight condition.

2.17.1 TOPCOAT® COATING

Topcoat Coating can be applied to the EverGuard EPDM membrane or flashing to offer a reflective surface, and add to its service life. In addition, the Topcoat product can be applied to existing EverGuard EPDM roofs. Should the coating of an existing roof be considered, the roof system should first be inspected by an EverGuard Approved contractor to assure that the system itself is not in need of repair prior to applying the Topcoat Coating.

Refer to the Product Data Sheets, Application Specifications, and Material Safety Data Sheets for Topcoat Coatings for additional information on application, storage and safety.

2.18.1 ROOF WALKWAYS

A. Lay Out EverGuard® EPDM Walkway Pads:

1. Install walkway pads in locations as specified by the project designer and in accordance with the System Design Guide Section of this Manual. Lay out EverGuard EPDM Walkway Pads so that the flat surface is over the completed EverGuard EPDM Membrane, spacing each pad a minimum of 1" (25.4 mm) and a maximum of 3" (76 mm) from each other to allow for drainage.
2. If EverGuard EPDM Walkway Pads must be installed over field-fabricated seams or within 6" (152 mm) of a seam edge, install EverGuard EPDM Flashing Tape over the seam edge. The EverGuard EPDM Flashing Tape must extend beyond the walkway pad a minimum of 6" (152 mm) on either side.

B. Attach EverGuard EPDM Walkway Pads to the Membrane:

1. **Clean the Membrane:**
Clean the membrane using EverGuard EPDM Primer where the EverGuard EPDM Seam Tape will contact the membrane.
2. **Place Walkpad:**
Remove the release paper from the EverGuard EPDM Seam Tape. Turn the walkpad over and place it in the EverGuard EPDM Primer.
3. **Apply Pressure:**
Walk on the pad to press in place assuring proper adhesion.

2.19.1 SHEET METAL WORK

- A.** For specific installation instructions for EverGuard EPDM Sheet Metal, refer to the System Design Guide and Technical Information Section of this manual.
- B.** For sheet metal work not supplied by EverGuard EPDM, refer to fabrication and installation requirements specified by the project designer as well as industry standards.

END OF SECTION